

JetSort cleaning procedures

Daily cleaning of JetSort machines is recommended to ensure maximum productivity and reliability.

Recommended Cleaning Materials

CAUTION

Simple Green, the recommended cleaning agent, can be an eye irritant. Avoid eye contact. If eye contact occurs, flush eye(s) with cool water for 5 minutes – remove contact lenses if present – continue flushing eye (s) with cool water for 15 more minutes. If irritation persists, consult physician.

Individuals with sensitive skin should rinse hands after using.

- Simple Green Safety Towels. (Part number: 022-2118-00.) A pre-moistened microfiber towel also may be used. If using Simple Green concentrate, dilute to: 30 ml of Simple Green per 240 ml of water. For material-safety-data sheets, see simplegreen.com.
- Microfiber towels. (Part number: 022-2223-00.)
- Vacuum cleaner. (In the United States: Order standard vacuum part number 022-1959-00 or heavy-duty vacuum part number 022-1308-00. Outside of the United States: Buy vacuum locally.)

Daily Cleaning

WARNING

High-voltage levels may be present. Risk of electric shock.

Turn power OFF and unplug power cord from machine before cleaning.

NOTICE

To avoid machine/component damage and potential voiding of existing warranty, follow these procedures:

Only use the specified tools for cleaning machine. Never use metal tools.

If using Simple Green concentrate, dilute to: 30 ml of Simple Green per 240 ml of water.

Never use cleaners containing ammonia. Ammonia may remove labels from machine.

Never spray cleaners directly on machine components.

NOTICE

Clean sort disk only as instructed. Do not attempt to remove oil coating on disk. Removing oil from disk negatively impacts performance and may negate disk warranty.

If disk cannot be cleaned with a clean, dry microfiber towel or cotton cloth, contact a Cummins Allison service representative for assistance.

Clean sorting chamber of at least once a week to remove accumulated coin dust and debris.

1. Remove the coin tray.
2. Remove any stray coins or other objects from the inside of the machine by hand.
3. Use vacuum to remove accumulated dust or debris from interior areas.

Inspect the sort disk and pad daily for best machine performance. Never wipe sort disk or pad, except as instructed in this document.

1. Raise and inspect the sort disk for debris and remove by hand.
2. Clean disk if needed using dry microfiber towel, a clean cotton cloth, or a soft, non-metallic brush.
3. If necessary, use a stiff, non-metallic brush to clean the grooves on the underside of the top disk.
4. Inspect sort pad for any cuts that may affect the sorter's accuracy. Replace pad if needed. Replacement sort pads are available from your Local Cummins Allison branch office.
5. Replace the sort head and secure the latch.
6. Reinstall coin tray and secure in place.



Correct: disk is secured



Incorrect: disk is not secured

7. Clean remaining exterior surfaces as needed with a Simple Green Safety Towel.